

News Release

Release Date: Immediate

Source: *Intercon 1* / Nortech Systems, Inc.

Item: *InterFlex*[™] Camera Link[™] Cable and Assemblies

Intercon 1, the largest producer of camera cable and assemblies in the United States announces the premier release of the 89878-11P Camera Link[™] cable. This cable is designed to CameraLink[™] standards, used in camera to frame grabber interface, and it provides cable flex life of over 1 million cycles for demanding industrial, medical, and scientific applications.

This 100-Ohm, individually shielded, twisted wire pair cable product incorporates unique *InterFlex*[™] extended life-cycle characteristics and offers precise signal transmission for all Camera Link[™] interfacing equipment. Overall cable construction consists of eleven 28 AWG (19x40) shielded pairs, four 28 AWG drain wires, PTFE tape wrap for cycle life, 90% minimum coverage dual reverse spiral serve shielding, and a tube PVC jacket formulated with advanced compounds.

Cable and cable assemblies using 3M MDR connectors with 30 μ" gold and positive retention thumbscrew locking will be available prior to July 1st. Molded assemblies will be offered during the 2nd quarter of 2001 at no additional cost.

Questions regarding the *InterFlex*[™] Camera Link[™] cable and assemblies should be directed to Customer Service at: **Voice:** 800.237.9576, **Fax:** 218.765.2300, or **email:** intercon@nortechsys.com.

##